AIR SHOWERS AND AIR SHOWER TUNNELS

Air Showers offer an effective way to reduce contaminants carried by individuals entering or leaving a controlled area. The Air Shower con be the solution to many decontamination problems

Air Shower Tunnels are protected passageways that allow large quantities of personnel to pass into controlled areas.

Air Showers and Tunnels supply concentrated CLASS 100 sterile air flows to remove contamination while an individual stands in or walks through a specially constructed air chamber. Pressurized air streams from nozzles at a velocity ranging from 6,000 to 8,000 feet per minute. This ensures the efficient scrubbing action necessary for the removal of particulate matter. Contaminated air is directed downward through the grilles and hollow walls of the Air Shower to the filter. Particles as small as 0.3 microns are removed with 99.97% efficiency.

Ultrapure Technology Air Shower Tunnels are used as downflow booths to remove particulate contamination from personnel entering clean rooms and sterile rooms. The Air Shower Tunnel is designed as a combination of basic floor plan styles placed either side by side or end to end. Air Showers and Tunnels meet all federal, military and industrial specifications for use with life science, bio medical, pharmaceutical, parental drua, microelectronic, aerospace, precision manufacturing and other applications. All Air Showers

and Air Shower Tunnels manufactured by Ultrapure Technology are warranted for a period of one year from the date of delivery.

Ultrapure Technology Air Showers and Air Shower Tunnels are economical to operate and require minimal maintenance.



SPECIAL AIR SHOWER FEATURES

- Light switch, audible alarm and alarm reset
- Four-line, 64-character alpha/numerical LCD display which monitors system function during normal operation and displays menu functions for service and system key changes.
- Sixteen Key membrane keypad for system operation
 - -Four number code to turn control on and off
 - -Four number code to access system set-up
- Microprocessor Programming Capabilities
 - -Time of day
 - -Day of the week
 - -Cycle time
 - -Delay unlock time
 - -Designate entry and exit doors
 - -Replace entry system four-digit code
 - -Initiate time-lock feature
 - -Initiate security locking feature with a four-digit code
 - -Initiate single direction access feature

- Microprocessor Diagnostic Capabilities
 - -Air Shower disabling feature
 - -Blower operations check
 - -Door switch operations check
 - -Door lock operations check
 - -Presence sensor/mat switch check
 - -Record blower operating hours
 - -Record Air Shower cycle
- Standard interlocking doors which release automatically with power failure
- Standard fluorescent lighting contained in the ceiling to reduce turbulence
- Optional HEPA Ceiling provides a constant laminar flow to increase protection of the area
- Optional Ion Bar static eliminators when required
- Safety feature which automatically releases door locks in the event of a power failure
- Emergency stop button on each Air Shower which releases locks for exiting while sounding an alarm.

AIR SHOWER ELECTRICAL REQUIREMENTS Three Phase Voltage

HP	MOTOR	BLOWER	VOLTAGE	AMPS
5HP	3N669	4C330	208V	15.3
			460V	6.8
2HP	3N667	4C329	208V	7.0
			230V	6.6
			460V	3.3


^{*}Other voltages available upon request

PERSONNEL AIR SHOWERS

MODEL 337 347 357 367 447 457 467 557 567 667 3127	3157
MODEL 337 347 357 367 447 457 467 557 567 667 3127	0101
Base Section Ht. 90 90 90 90 90 90 90 90 90 90 90	90
Width 52 52 52 52 58 58 64 64 70 52	52
Length 44 56 60 72 56 60 72 60 72 72 144	180
Blower Box 26 26 30 30 30 30 30 30 30 30	30
Height	
Door Width 36 36 36 36 36 36 42 42 49 30	30
Width-ID 35 I/2 35 I/2 35 I/2 35 I/2 41 I/2 41 I/2 47 I/2 47 I/2 53 I/2 35 I/2	35 1/2
Length-ID clear 35 47 51 63 47 51 63 51 63 63 135	171
Number of 20 20 32 36 32 36 32 36 40 60	96
Nozzles	
Quantity of I I I I I I I I 3	3
Blowers	
CFM/blower @2" 1010 1010 1820 1820 1820 1820 1820 1820	5460
WG	
RPM 3600 3600 3600 3600 3600 3600 3600 360	3600
Wheel Diameter 12 1/2 12 1/2 13 1/2 1	12 1/2
3 door available no no yes yes no yes yes yes Yes yes	Yes
Shipping Weight 1600 1800 1900 2100 1800 2000 2200 2000 2200 2400 5300	5700
Filter: II ½ deep x 18x24 18x24 24x24 24x24 24x24 24x24 24x24 24x24 24x24 24x24 24x24 3-18x24	3-24x24
H-P- 2 2 5 5 5 5 5 5 3-2HP	3-5HP


HFC Model —for HEPA Filter Ceiling Model add 6" to base section height.

SPECIAL SIZES ARE AVAILABLE UPON REQUEST.



STANDARD AIR SHOWER COMPONENTS

- Motor/Blower assembly
- Power control box
- Emergency release button
- HEPA filter 99.7% effective on 0.3 micron particles
- Adjustable nozzles
- Fluorescent light fixture
- Automatically activated floor switch
- Anodized aluminum doors with plexiglass
- Microprocessor control panel
- Access panels for easy maintenance
- Electric interlocking chamber
- Single connection junction box
- Construction: High-Density 7/8" particle board laminated with plastic [Formica or equivalent]
- In accordance with our policy of continual product improvement, Ultrapure Technology reserves the right to incorporate and use equipment and material to conform with the latest design of its products while maintaining the specifications of the equipment.



OPTIONAL EQUIPMENT

- Epoxy Painted cold rolled steel and stainless steel
- Safety plate glass doors
- Magnehelic gauge HEPA and pre-filter
- Knock-down assembly
- Side-mounted HEPA and motor/blower
- Ceiling-mounted HEPA filter which provides a constant laminar flow for added protection

- Ion bar static eliminators
- Raised floor return
- Explosion-proof construction
- Water misting systems
- Magnehelic gauges with alarms
- Aluminum grated floor with clean-out pan